



w102 Chipperfield Instructions

Page 1 / 4


Wästberg
Box 5085
200 71 Malmö
Sweden
wastberg.com



1.



2.



EN Mounting instructions

1.

Attach the plug to the adapter and connect the power cord.

2. **Table**

Turn the button to turn the light on and off and to dim the light.

3. **Pin**

Place the pin through a Ø15 mm hole.


4.

Secure with the nut under the table.


5.

Push the button to turn the light on/off.
Hold the button to dim.


3.




4.




5.




6.




7.




8.




9.



5.



6.



EN Mounting instructions

6. Floor

Mount the base with the screw.

7. Wall

Mount the bracket to the wall (screws are not included).

8.

Place the lamp on the bracket.

9. Floor & wall

Fasten with the screws.

10.

Press to turn the light on and off.
Press and hold to dim the light.


11.

The lamp arm and head can be rotated.



This product is made of solid brass/steel.
The surface has been treated to protect it from
discoloration, stains, etc.

The surface is still sensitive, clean only with a soft dry
cloth. Do not polish.




This product contains a light source of energy
efficiency class G. The light source is replaceable by
Wästberg or by a professional with explicit authorisa-
tion. For more information please contact your local
Wästberg customer service point.


w102 Chipperfield Instructions

Page 3 / 4


Wästberg
Box 5085
200 71 Malmö
Sweden
wastberg.com



1.



2.



sv Monteringsanvisningar

1.

Anslut kontakten till adaptern och anslut strömsladden.

2. **Bord**

Bord: Vrid på knappen för att tända och släcka lampan och för att dimra ljuset.

3. **Stift**

För in stiftet genom ett hål med 15 mm i diameter.


4.

Fäst med muttern under bordet.


5.

Tryck på knappen för att tända och släcka lampan. Håll knappen intryckt för att dimra ljuset.


3.




4.




5.




6.




7.




8.




9.



5.



6.



sv Monteringsanvisningar

6. Golv

Montera basen med skruven.

7. Vägg

Montera fästet på väggen (skruvar ingår ej).

8.

Placera lampan på fästet.

9. Floor & wall

Fäst med skruvarna.

10. Golv och vägg

Tryck för att tända och släcka lampan. Håll knappen intryckt för att dimra ljuset.


11.

Lampans arm och huvud kan vridas.



Denna produkt är tillverkad av massiv mässing/stål. Ytan har behandlats för att skydda den mot missfärgning, fläckar etc.

Ytan är fortfarande känslig, rengör endast med en mjuk, torr trasa. Polera inte.



Denna produkt innehåller en ljuskälla med energieffektivitetsklass G. Ljuskällan kan bytas ut av Wästberg eller av en professionell med uttryckligt tillstånd. För mer information, kontakta din lokala Wästberg-kundtjänst.