

w227 Winkel alu Instructions


Page 1 / 2

Wästberg
Box 5085
200 71 Malmö
Sweden
wastberg.com




1.

a)




b)




2.


a)



b)



3.



EN Mounting instructions

1. Pin

a) Cord through the table top: Place the cord in the slot inside the pin. Place the pin through a Ø14mm hole with one disc above and one under the table. Secure with washer and nut under the table.

b) Cord above the table top: Place the pin through a Ø14mm hole. Secure it with the washer and nut under the table.

2.

Attach the lamp.

3. Base

Attach the lamp to the base.

4.

Attach the plug to the adapter.


5.

Connect the power cables.


6.

Press to turn the light on and off. The lamp has an 8 hours timer. Press and hold to dim the light.



4.



5.



6.



This product contains a light source of energy efficiency class F. The light source is replaceable by Wästberg or by a professional with explicit authorisation. For more information please contact your local Wästberg customer service point.

w227 Winkel alu

Instructions


Page 2 / 2

Wästberg
Box 5085
200 71 Malmö
Sweden
wastberg.com




1.

a)




b)




2.


a)




b)




3.




4.



5.



6.



sv Monteringsanvisningar

1. Fäst

a) Sladden genom bordsskivan: Placera sladden i spåret inuti stiftet. För in stiftet genom ett hål med diameter 14 mm med en skiva ovanför och en under bordet. Fäst med bricka och mutter under bordet.

b) Sladden ovanför bordsskivan: För in stiftet genom ett hål med diameter 14 mm. Fäst det med bricka och mutter under bordet.

2.

Fäst lampan.

3. Bas

Fäst lampan på basen.

4.


Fäst adaptern på kontakten.

5.

Anslut strömkablarna.

6.

Tryck för att tända och släcka lampan. Lampan har en timer på 8 timmar. Håll intryckt för att dimra lampan.



Denna produkt innehåller en ljuskälla med energieffektivitetsklass F. Ljuskällan kan bytas ut av Wästberg eller av en professionell med uttryckligt tillstånd. För mer information, kontakta din lokala Wästberg-kundtjänst.